





# Modification CRT 3DB

Maintenir appuyée la touche **MENU**, et allumer l'appareil. Relacher la touche **MENU**, l'écran indique **RESET ?** Appuyer de nouveau sur la touche **MENU** puis avec la touche  rechercher l'affichage **BAND**, valider avec la touche **MENU**. L'afficheur indique **PSWD**, taper **5858** sur le clavier. L'afficheur indique **BAND 1** 144-146, taper 136174 puis avec la touche  afficher **BAND 2** 430-440, taper 400470, de nouveau la touche  **BAND 3** taper 350390 et enfin  **BAND 4** taper 470520 puis valider avec la touche **MENU**.


Les bandes 3 et 4 fonctionnent uniquement en réception.

L'appareil fonctionne maintenant en VHF entre 136 et 174 MHz, en UHF entre 400 et 470 MHz TX-RX

Egalement entre 350 et 390 MHz, ainsi que entre 470 et 520 MHz en réception uniquement

Pour bloquer à nouveau l'appareil il suffit de refaire l'opération en sens inverse.

---

Hold **MENU** key and turn on the radio, release **MENU** key. The display show **RESET ?**. Press **MENU** key then  to display **BAND**, confirm by **MENU** key.

LCD display **PSWD**, input **5858** with the keypad, the display show **BAND 1**

144-146, input 136174 then press  to display **BAND 2** 430-440 input

400470, press  to display **BAND 3** input 350390, press  to display **BAND**

**4** input 470520 confirm by **MENU** key.

BAND 3 and 4 work only on RX mode.

The radio work now between 136/174MHz VHF and 400/470MHz UHF TX/RX.

Also between 350- 390 MHz and 470-520MHz RX mode only

